



KTM/HVA 85 SX - Fitting Instructions

Move the rubber to the other side of the mounting point on the frame to fit the DEP Pipe as shown in photos below. Ensure the silencer and the front pipe are loosely mounted and once all mounting holes are aligned then tighten the fasteners fully. This applies for when fitting silencer and front pipe or, when fitting a silencer only to stock front pipe

